

ATOM[®]

BY CRITICAL[®]



PRESS TO TURN OUTPUT ON AND OFF




ROTATE TO CHANGE VOLTAGE

TATTOO MACHINE OUTPUT

POWER INPUT


FOOT PEDAL INPUT



COLOR VOLTAGE REFERENCE CHART

FOR MOMENTARY/MAINTAINED PEDAL MODES AND JUMP START FEATURE

PRESS AND HOLD ENCODER BUTTON



FIRST FLASH TOGGLES BETWEEN
MOMENTARY/MAINTAINED PEDAL MODES

SECOND FLASH ENABLES/DISABLES
JUMP START FOR HARD STARTING
ROTARY MACHINES

BUILT IN MAGNETS FOR
EASY MOUNTING

